

- ◆ CB-900 Blower
- ◆ CB-900B Blower
- ◆ CB-900C Blower
- ◆ CB-900D Blower
- ◆ CB-900E Blower



Never dispose of this product in a landfill. Please see instructions for environmental disposal.

Subagency

3-speed blower



CONTENTS

| | |
|--|-----|
| Chapter I : Description | 1 |
| Chapter II : Cautions | 1 |
| Chapter III : Main Technical Parameters | 2 |
| Chapter IV : Operation Methods of Products | 2 |
| Chapter V : Care and Maintenance | 3 |
| Chapter VI : Main Troubles and How to Solve Them | 3 |
| Chapter VII : Explosion Views | 4-7 |

Chapter I : Description

Welcome to purchase and use our fans. The machine is characterized by easy operation, safe use and good drying and ventilation effect. It is especially suitable for guesthouses, hotels, office buildings, exhibition facilities and large public spaces. After cleaning the carpet ground, it can also be used to ventilate and dissipate heat, it is convenient to move because of the flexible design of draw bar.

Chapter II : CAUTIONS

1. This machine is not intended for use by the physically weak, intellectually obtuse or mentally disabled people (including children), unless it is safely used under the help or instructions of those who are responsible for their safety
2. The children shall be supervised to ensure that they will not play the machine.
3. Be sure to remove the power plug from the socket before cleaning or repairing the machine.
4. If the power cord is damaged or loose, it shall be replaced by the manufacturer's service department or qualified personnel; the connection shall be of Y type
5. Remove the power plug after stopping the machine
6. The supplied power must be matched with motor voltage and frequency.
7. Once the machine is damaged, please do not handle it by yourself or discard in the trash can but promptly notify the professional organization so as not to cause environmental pollution. See the icons at the back cover!

See icons in back cover!

Chapter III: Main Technical Parameters

Power: 900W

Voltage: 110V-230V

Current: 4A

Frequency: 50Hz

Capacitor: 40UF

Air delivery: L-gear 110^{m³}/min M-gear 120^{m³}/min B-gear 160^{m³}/min

Speed of rotation: 1000RPM 1200RPM 1400RPM

Fan wheel size: 270mm

Power cable: 3×2mm²×7m

Packaging: 1 unit/box

Type: CB-900/CB-900B/CB-900C/CB-900D

colors: Red, gray, orange, blue, black

Chapter IV: Operation Methods of the Products

1. Fan switch is the three-position switch and its symbols are "O" "L" "M" and "H".
2. On the red knob gear switch, round point at the "0" position indicates neutral (stop) gear, "L" indicating the first gear, "M" the second gear and "H" the third gear.
3. Before turning on the power, check the knob switch round point whether or not points at "0". After confirming, turn on the power and turn the knob switch clockwise. Choose a different gear-speed on different occasions. The fan can not be moved when it is under operation in case of any danger.

Chapter V: Care and Maintenance

1. This product is not waterproof, the water cleanser is not allowed into motor body in case of any electric shock accident.
2. Do not dismantle or replace the main accessories of motor, if there is any abnormal phenomenon, please find the company or distributor to repair it.

Chapter VI: Main Troubles and How to Solve Them

| Trouble | Possible fault reasons | How to Solve |
|---|---|--|
| The motor does not rotate | ①The power cable is not connected correctly ②Loose power cord with power switch ③The motor is burnt | ①Check for power wire ②Check circuit at switch position. ③professional personnel for repair |
| The motor startup is slow | CBB61 450V. AC 20UF Capacitor is damaged | Ask the manufacturer's service or professional personnel for repair and replace the motor |
| When starting the machine, there is abnormal sound. | Damage the wind wheel and deform the fan shell in the transport process. | Ask the manufacturer's service department or professional personnel for repair and replace the wind wheel or chassis |