




Machinery | Spares | Consumables
(Specialist suppliers to Tool Hire & Garden Machinery Dealers)


GP2660HC Parts List





Item No.	Part No.	Description
1	GP02020070064	Safe Guard
2	GP02020070066	Retaining Plate
3	GP02020070063	Blade
4	GP02020160144	Spacer
5	GP02020070065	Blade Backstop
6	GP03010070010	Screw
7	GP02020070069	Blade Cover
8	GP03010110073	Screw
9	GP70070080064	Gear Case Lid
10	GP02020160021	Plate
11	GP02070010105	Gasket
12	GP02090030003	Felt
13	GP03010010010	Screw
14	GP03010010021	Screw
15	GP02020160215	Retainer
16	GP02020090008	Transmission Arm
17	GP03090010022	Bearing
18	GP02020090043	Eccenter
19	GP02020090004	Gear Shaft
20	GP03010010026	Screw
21	GP03120020003	Ring
22	GP03090010020	Ball Bearing
23	GP02020090045	Eccentric Spindle
24	GP02020160465	Plate
25	GP03030060009	Lock Nut
26	GP70070010019	Gear Case
27	GP03010110043	Butter Nib
28	GP02020050027	Drum
29	GP70030030348	Handle
30	GP03020020033	Screw

Item No.	Part No.	Description
31	GP03010040010	Tapping Screw
32	GP70030070251	Right Handle
33	GP70030160014	Bracket
34	GP02020110054	Spring
35	GP03010040061	Tapping Screw
36	GP03040010013	Washer
37	GP02050050127	Stop Button Comp
38	GP02050040102	Cable Comp
39	GP70030070225	Hand Grip
40	GP70030070258	Left Handle
41	GP70030070232	Throttle Lever
42	GP02020110055	Torsion Spring
43	GP70030180177	Spring Seat
44	GP02020110056	Spring
45	GP03020020052	Screw
46	GP70030180184	Frame
47	GP02020110053	Spring
48	GP03020020025	Screw
49	GP70030160072	Spring
50	GP03010010014	Screw
51	GP03050010012	S.washer
52	GP03040020015	Washer
53	GP03010040013	Tapping Screw
54	GP03050010016	S.washer
55	GP03010010008	Screw
56	GP02500030272	Aluminized Paper
57	GP02050010025	Muffler Pipe
58	GP02020160560	Lock Block
59	GP02020150013	Washer



Item No.	Part No.	Description
1	GP03020010013	Screw Assy
2	GP03040050021	Plain Washer
3	GP70030030128	Housing,Cylinder
4	GP02070010049	Spacer
5	GP03130010013	Spark Plug
6	GP03010010061	Socket Head Screw
7	GP70070130001	Cylinder
8	GP02070010025	Gasket,Cylinder
9	GP02020020003	Ring,Piston
10	GP02020030017	Snap Ring
11	GP02010020006	Piston
12	GP02020010004	Pin,Piston
13	GP03090020018	Needle Bearing
14	GP02020150007	Thrust Washer
15	GP02020120028	Crank Shaft
16	GP03070010001	Key
17	GP03090010028	Bearing
18	GP03100010009	Oil Seal
19	GP70070050019	Rear Crankcase
20	GP03040020019	Plain Washer
21	GP03050010014	Spring Washer
22	GP03010010045	Socket Head Screw
23	GP02050030032	Flywheel
24	GP02050100012	Starter Pulley Assy
25	GP03030070009	Square nut
26	GP02050070047	Starter Assy

Item No.	Part No.	Description
27	GP03020020010	Screw Assy
28	GP03020020051	Screw Assy
29	GP70030030452	Housing,Muffler
30	GP03010010049	Socket Head Screw
31	GP02020160374	Housing,Muffler
32	GP02050010024	Muffler Assy
33	GP02070010145	Gasket,Muffler
34	GP03020020013	Screw Assy
35	GP02050050144	Lead Wire
36	GP02050030001	Ignition Coil Assy
37	GP02070010048	Insulating Gasket
38	GP03040010007	Plain Washer
39	GP02070010110	Gasket,Crankcase
40	GP03060010002	Locating Pin
41	GP70070050020	Front Crankcase
42	GP70070080018	Base,Clutch Assy
43	GP03040050052	Washer
44	GP02050160002	Clutch Assy
45	GP03040050042	Wave Washer
46	GP02020130001	Clutch Bolt
47	GP02070010078	Insulator Gasket
48	GP02110030036	Insulator
49	GP02070010061	Carburetor Gasket
50	GP02050020049	Carburetor
51	GP02070010099	Gasket,Cleaner Base
52	GP02110030070	Choke Lever

Item No.	Part No.	Description
53	GP70030040056	Base,Cleaner
54	GP70030040028	Choke
55	GP03010040054	Tapping Screw
56	GP02020160073	Baffle Plate
57	GP03020020036	Screw Assy
58	GP02090010011	Element
59	GP70030040081	Cover,Cleaner
60	GP02110030002	Knob
61	GP01040010011	Fuel Line
62	GP02050020127	Primer Pump
63	GP01040010011	Return Tube
64	GP02080030025	Rubber Plug
65	GP01040010011	Inlet Tube
66	GP02110030050	Plastic Washer
67	GP02050120002	Fuel Filter
68	GP70050030013	Fuel Tank
69	GP03040010009	Plain Washer
70	GP02110020026	Fuel tank lid comp.
71	GP03010110046	Screw Insulator
72	GP02080030001	Rubber Plug
73	GP02500030272	Aluminized paper