




**Machinery | Spares | Consumables**  
(Specialist suppliers to Tool Hire & Garden Machinery Dealers)


# GP26BV Parts List





Item No.	Part No.	Description
1	GP70050010068	Inlet Pipe (No. 1)
2	GP70050010069	Inlet Pipe (No. 2)
3	GP03010060056	Screw (M5x16)
4	GP03040020020	Washer 5
5	GP70030030284	Connect Cover
6	GP03010060078	Screw (M5x10)
7	GP70030180100	Connector Safety Cover
8	GP02050050002	Safety Switch
9	GP70030070032	Button Connector
10	GP03040050017	Washer 6
11	GP70030180012	Screw
12	GP70030030303	Fan Net Cover
13	GP02020160312	Wrest Spring Shaft
14	GP02020110048	Wrest Spring
15	GP70030010071	Rear Cochlea Cass
16	GP03030020002	Nut (M8x1)
17	GP02020070042	Shatter Tooth
18	GP70030090006	Impeller
19	GP03010010045	Screw (M5x30)
20	GP02080020046	Left Handle Rubber Cover
21	GP70030010055	Front Cochlea Case
22	GP02020160117	Pedestal
23	GP70050030063	Fuel Tank
24	GP03010040057	Nst5*20
25	GP70030160093	Lower Handle
26	GP02020160398	Throttle Lever Shaft
27	GP70030070109	Throttle Lever Handle
28	GP02050050111	Stop Switch Comp
29	GP02050050171	Short Stop Wire
30	GP70030160048	Upper Hangle
31	GP02080020046	Right Hangle Rubber Cover

Item No.	Part No.	Description
32	GP03010040017	St4.2 10
33	GP02050050171	Stop Wire
34	GP51010040002	Gasoling Enging
35	GP03040050022	Washer
36	GP02060020003	Starter Pope Reel
37	GP02060020009	Cole Spring
38	GP70080100004	Ebv260bn
39	GP03020020041	Screw M5 30
40	GP01050010009	Starter Pope
41	GP70030140013	Starter Handle
42	GP70050010070	Tail Pipe
43	GP02050040087	Throttle Wrie Comp
44	GP02050060050	Leaves Assy
45	GP02050060022	Harness Assy
46	GP01040010003	Return Fuel Pipe(L=70)
47	GP02080030025	Fuel Pipe Rubber Bung
48	GP01040010014	Inlet Fuel Pipe(L=220)
49	GP02050120002	Filter Cleaner
50	GP02110020026	37F
51	GP03050010007	Washer 8
52	GP03040050005	Washer 23*8*1
53	GP70050010066	Blow The Breeze Tube A
54	GP70050010067	Blow The Breeze Tube B
55	GP02050070048	Guide,Rope
56	GP02040030020	Bushing
57	GP02080030015	Plug,Lead Wire
58	GP03110020023	"O" Sealing Washer
59	GP03010060076	Screw M5 30
60	GP03020020018	Screw M5 10
61	GP03050010015	Washer 5
62	GP03010040048	Qc/T713



Item No.	Part No.	Description
1	GP03130010013	Spark Plug RCJ6Y
2	GP03010010061	Bolt M5x20
3	GP70070130011	Cylinder
4	GP02070010020	Gasket,Cylinder
5	GP02020020003	Piston Ring
6	GP02010020006	Piston
7	GP02020010004	Pin,Piston 8X28
8	GP02020030017	Ring, Snap
9	GP03090020018	Needle Bearing
10	GP02020150007	Thrust Washer
11	GP02020120026	Crank Shaft Assy
12	GP03090010028	Bearing 6001/P5
13	GP03060010002	Pin B3x10
14	GP02070010110	Gasket,Crankcase
15	GP03050010014	Rear Crankcase
16	GP03100010009	Oil Seal 12X22x7
17	GP03120030003	Stop Ring
18	GP70070080010	Starter Pulley
19	GP02020110088	Starter Pawl Spring
20	GP70030140014	Starter Pawl
21	GP03070010001	Woodruff Key
22	GP70070050001	Front Crankcase
23	GP03010010045	Bolt M5x30

Item No.	Part No.	Description
24	GP02050030018	Rotor
25	GP02070010078	Gasket,Insulator
26	GP02110030031	Insulator
27	GP03020020012	Bolt Assy M5x20
28	GP02070010061	Gasket,Carburetor
29	GP02050020045	Carburetor Comp
30	GP70030040038	Choke Handle
31	GP70080120007	Cleaner Inside Cover
32	GP70030040028	Choke
33	GP03010040008	Bolt St4x10
34	GP02090010011	Air Filter Element
35	GP03020020030	Bolt Assy M5x60
36	GP70030040078	Cover, Cleaner
37	GP70030180012	Knob,Cover
38	GP02070010141	Gasket,Muffler
39	GP02050010018	Muffler Assy
40	GP03040020019	Washer 5
41	GP03050010014	Washer 5
42	GP03010010049	Screw M5x50
43	GP03040010007	Washer 4
44	GP02070010048	Space,Ig Coil
45	GP02050050141	Stop Wire
46	GP02050030024	Ignition Coil Comp
47	GP03020020013	Screw M4x20