



THE HIRE SUPPLY COMPANY (UK) LTD.

ELITE 2KW FAN HEATER



MODEL NO. FH06

INSTRUCTION MANUAL

SAFETY INSTRUCTIONS

1. Read all instructions before using the fan heater.
2. Only connect the fan heater to a socket with a mains voltage as specified on the rating plate.
3. Do not leave your home while the appliance is in use: always ensure that the mains switch is in the OFF (0) position and the thermostat dial is in minimum position. Always unplug the appliance, when not in use.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the safe use of the appliance by a person responsible for their safety. Children should be supervised at all times to ensure that they do not play with the appliance.
5. Do not use the appliance near bathtubs, showers, wash basins or swimming pools.
6. Do not place anything directly in front of the heater.
7. Do not cover. If covered there is a risk of overheating and potential fire.
8. Keep the air inlet and outlet free from objects at least 1m in front and behind the heater.
9. Do not unplug the appliance by pulling the power cord.
10. Do not expose the appliance to atmospheric conditions (rain, sun, etc.)
11. Keep combustible material such as furniture, cushions, bedding, paper, clothes, curtains etc at least 1 metre away from the appliance.
12. If the mains cord of the appliance is damaged, please contact your supplier or a qualified electrician and stop use straight away.
13. Keep the fan heater clean. Do not allow any objects to enter any ventilation or exhaust opening as this may cause electric shock, or fire and damage to the heater.

OPERATION

Select the speed by the turning the knob clockwise.

- = OFF.
- ↶ = COOL AIR
- ~ = WARM AIR (1000W)
- ≡ = HOT AIR (2000W)

THERMOSTAT

Turn the thermostat knob clockwise up to the highest position. Select the speed turning the knob clockwise (see OPERATION) When the desired temperature is attained turn the thermostat counter-clockwise slowly until the appliance is switched off (the pilot lamp is off)
The ambient temperature is automatically maintained.
If you turn the thermostat knob clockwise and you reach the highest position your fan heater will continuously work.

SAFETY DEVICE

This appliance is provided with a safety device disconnecting the appliance in case of overheating.
To deactivate the safety device switch off the appliance and unplug it until it gets cold (about 10 minutes). Plug it again and switch it on.
If the appliance is still off unplug it and take to your supplier.

MAINTENANCE

Before cleaning always remove the plug from the electrical socket.
Clean the air inlet/outlet grills of dust frequently
Do not use abrasive powders or solvents.

TECHNICAL DATA

Voltage	230V~ 50Hz
Power consumption	2000W
Class of insulation	II

1 Year Warranty



THE HIRE SUPPLY COMPANY (UK) LTD.

BUILDING NO 2
SHEET STORES IND EST
LONG EATON
NG10 1AU